

terminal configurations

Type	Front	Side	Top	Battery Type	
A				UTX16-BS-1 UB7C-A	UTX16-1 UB14-A1
C				I2N24-3	
D				UB30CL-B UTX15L-BS UTX14AH-BS UTX14AHL-BS UTX16-BS	UB12C-A UTX14 U50-NI8L-A3 UTX20-BS UTX20L-BS
E				UTX14L	
F				6N6-3B B39-6 B54-6 B54-6A B38-6A	6UB11-2D I2N5.5A-3B I2N5-3B I2N5-4B I2N7-3B
G				SU50-NI8L-AT U50-NI8L-A-LM UB18-A UB18L-A	I2N5.5-4A UB16B-A
HD				UBVT-1 UBVT-2 UBVT-3	UBVT-4 UBVT-5 UBVT-6 UBVT-7 UBVT-8
I				UHD-12 UBVT-7	
IT				UTS1913-22	
J				53030 51913 U60-N24-A	
K				UT7B-BS UT9B-BS UTR9-BS UTZ10S-BS	UT12A-BS UT12B-BS UT14B-BS UTZ14S-BS
L				UT4B-BS	
M				6N6-1D 6N5.5-1D	
N				6N6-1B 6N6-1B-1	
O				UB2.5L-C 6N6-1D-2	6N4B-2A-3
P				6N4-2A-3	
Q				6N4-2A-4 6N2-2A	
R				6N4-2A 6N4B-2A	
S				6N2-2A-4	
T				6N2-2A-3 6N4A-4D	6N4-2A-5
U				2 Wires Red - Positive Blue - Negative	6N4C-1B
V				4 Wires Red - Positive Green - Negative	6N4B-2A-5 6N4-2A-6
W				4 Wires Red - Positive Green - Negative	6N4-2A-8
X				2 Wires Red - Positive Blue - Negative	6N2A-2C 6N2A-2C-1

