DECORATIVE ACCESSORIES AND ACCENT FURNITURE

ASSEMBLY INSTRUCTIONS

UTTERMOST

STYLE#: 21949


Careful unpack all lamp parts from the carton.


- 1. Take the lamp carefully out of the Carton, and place it on a flat surface.
- 2. Be sure the power to the installation point is power off.

3. Turn the **inner-threaded turning** counter-clockwise and move the **coupling** upward. (Picture 1)

4. Move the **metal cap** upward to allow space for **Glass Ball**. (Picture 2)

- 5. Slide the Glass Ball to allow the clips fit into the glass. (Picture 3)
- 6. Rotate the **Glass Ball** to allow the **clip** from other end fit into the **glass**. (Picture 4)
- 7. Put the **metal cap** downward to touch with the **glass top**. (Picture 5)
- 8. Turn the inner threaded turning clockwise until tightened (Picture 6)
- 9. Now you can enjoy your beautiful fixture.





PO BOX 558/3325 GRASSY HILL RD. ROCKY MOUNT, VIRGINIA 24151 www.uttermost.com