




ASSEMBLY INSTRUCTIONS

STYLE# 28564

Please make sure you have all the parts indicated above before you begin assembly of this item.

Carefully unpack all lamp parts from the carton.

1. Place the base in an upright position on the floor.
2. Thread Column B onto the base and turn clockwise to tighten secure.
3. Thread Column A onto Column B and turn clockwise to tighten secure.
4. Place the harp into the harp base.
5. Place the shade onto the harp, and tighten the finial.
6. Use 3-Way 150W bulb (not included).



IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock.

This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.