




UTTERMOST

# Assembly Instruction

STYLE: 28630

- 1. Take the parts carefully out of the carton, and place it on a flat surface, make sure that the parts will not be damaged.**
- 2. Insert tube(B) into base(A), and then use nut and flat washer to tighten.**
- 3. Screw tube(C) into tube(B) and tighten.**
- 4. Screw out the finial(F) from the harp(D), place the shade(E) onto harp(D), then secure the lamp shade by screwing the finial(F).**



PO BOX 558/3325 GRASSY HILL RD. ROCKY MOUNT, VIRGINIA 24151

[www.uttermost.com](http://www.uttermost.com)