

**INSTRUCTIONS**

Pour Standard Reference Solution into a clean container. Refer to meter manufacturer's instructions. Immerse meter electrode tip in Standard Reference Solution. After one minute adjust calibration so that the meter indicates the correct EC or PPM. Use the solution only once, then discard. Never pour used solution back into this bottle. Calibrate your meter frequently.

**Standard  
Reference  
Solution @ 25°c**  
*for calibration of  
EC and PPM  
Conductivity Meters*

**1500 ppM (NaCl scale)**  
**2190 ppM (442 scale)**  
**2930 S (microSiemens)**

**KEEP OUT OF REACH  
OF CHILDREN**

**STORE IN A COOL  
DARK PLACE**

**946 ml (1 QUART)**



Manufactured by GH Inc.,  
P.O. Box 1576 Sebastopol, CA 95473, USA

