Return to search	Print Page
and a second sec	Product 2 Number: 0 Order Abbreviation: General 2 Description: 1 ter 7
Prod	uct Information
Abbrev. With Packaging Info.	F025735EC0 30/CS 1/SKU
Actual Length (in)	35.78
Actual Length (mm)	908.0
Average Rated Life (hr)	20000
Base	Medium Bipin
Bulb	T8
Color Rendering Index (CRI)	75
Color Temperature/CCT (K)	3500
Diameter (in)	1.10
Diameter (mm)	27.9

Product Number:	21941
Order Abbreviation:	F025/735/EC0
General Description:	25W, 36" MOL, T8 OCTRON fluorescent lamp, 3500K color temperature, rare earth phosphor, 75 CRI, suitable for IS or RS operation, ECOLOGIC

Product Information	
Abbrev. With Packaging Info.	F025735EC0 30/CS 1/SKU
Actual Length (in)	35.78
Actual Length (mm)	908.0
Average Rated Life (hr)	20000
Base	Medium Bipin
Bulb	Т8
Color Rendering Index (CRI)	75
Color Temperature/CCT (K)	3500
Diameter (in)	1.10
Diameter (mm)	27.9
Family Brand Name	Octron® 700, Ecologic
Industry Standards	ANSI C78.81 - 2001
Initial Lumens at 25C	1950
Mean Lumens at 25C	1755
Nominal Length (in)	36
Nominal Wattage (W)	25.00

Additional Product Information	
Product Documents, Graphs, and Images	
Compatible Ballast	
Packaging Information	



http://ecom.mysylvania.com/sylvaniab2c/catalog/query.do?query=21941*

2/12/2009

Footnotes

- Approximate initial lumens after 100 hours operation.
- The life ratings of fluorescent lamps are based on 3 hr. burning cycles under specified conditions and with ballast meeting ANSI specifications. If burning cycle is increased, there will be a corresponding increase in the average hours life.
- The life rating of OCTRON and OCTRON Curvalume lamps operated on magnetic rapid start ballasts is 20,000 hours. The life rating of OCTRON and OCTRON Curvalume lamps operated on instant start electronic ballasts is 15,000 hours.
- Minimum starting temperature is a function of the ballast; consult the ballast manufacturer.
- OCTRON lamps should be operated only with magnetic rapid start ballasts designed to
 operate 265 mA, T-8 lamps or high frequency (electronic) ballasts that are either instant
 start, or rapid start, or programmed rapid start specifically designed to operate T8 lamps.
 OCTRON lamps may be operated on instant start ballasts with ballast factors ranging
 from a minimum of 0.71 to a maximum of 1.20 at the nominal ballast input voltage.
 When OCTRON lamps are operated in the instant start mode, the two wires or two
 contacts of each socket should be connected to each other. They should then be
 connected to the appropriate ballast lead wire using National Electric Code techniques.
- SYLVANIA ECOLOGIC fluorescent lamps are designed to pass the Federal Toxic Characteristic Leaching Procedure (TCLP) criteria for classification as non-hazardous waste in most states. TCLP test results are available upon request. Lamp disposal regulations may vary, check your local & state regulations. For more information, please visit www.lamprecycle.org

Print Page