

325 Campus Drive  
Beaver

Aurora, OH 44202

800-324-1496

## ELITE LENS INSTALLATION INSTRUCTIONS

The current Elite Quick Ship sku does not accept the new Elite Lens without a retrofit kit (EliteLensKit). This kit includes the new Elite Lens, 2 endcaps (LC102R) and 6 self tapping screws (LC214).



Step 1 The LC102R (endcap) installs over the existing endcap (LC102).



Step 2 Drill the 3 self tapping screws (LC214) into the existing endcap using the new endcap (LC102R) guide holes. Two screws from the top & one screw next to the knock-out.



Step 3 The Elite lens will now fit within the endcaps

