

# IMPORTANT SAFETY INSTRUCTIONS:

## (a) READ AND FOLLOW ALL SAFETY INSTRUCTIONS


- (b) Do not cover this product as the covering may cause the flexible light to overheat and melt or ignite.
- (c) Do not operate with the flexible light tightly coiled.
- (d) Do not puncture, cut, shorten, or splice the flexible lighting.
- (e) Do not route the cord or flexible lighting cable through walls, doors, windows or any like part of the building structure.
- (f) Do not use if there is any damage to the light or cord insulation. Inspect periodically.
- (g) Do not submerge flexible light in liquids, or use the product in the vicinity of standing water or other liquids.
- (h) Secure this flexible light cable using only the hangers or clips provided. Do not secure this product or its cord with staples, nails, or like means that may damage the insulation.
- (i) Do not subject flexible lighting to continuous flexing.

**WARNING: When using outdoor use portable lighting products, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury, including the following:**


### Read All Instructions

- (a) Ground Fault Circuit Interrupter (GFCI) protection should be provided on the circuits or outlet to be used for the outdoor use flexible lighting product. Receptacles are available having built-in GFCI protection for this measure of safety.
- (b) Use only outdoor extension cords, such as type SW, SOW, STW, STOW, SJW, SJOW, SJTW, or SJTOW. This designation is marked on the wire of the extension cord.


## USAGE OF FLEXILIGHT ACCESSORIES




- 1) With mounting clip (knock the nail into the board surface)
- (1) Use a nail to fix the mounting clip;
  - (2) Press the flexilight into the mounting clip.



- 2) With suction cups  
On the surface of glass or ceramic tile:
- (1) Press the suction cup on a glass surface or ceramic tile with glass pattern;
  - (2) Fix the flexilight on the cupules with mounting clip.



- 3) With Channel  
On glass surface:
- (1) Glue the channel on the glass surface;
  - (2) Press the flexilight in the channel.



- On the surface of wooden material
- (1) Fix the channel with nails;
  - (2) Press the flexilight in the channel.

## SAVE THESE INSTRUCTIONS

AC 120V, 60Hz, MAX 5A

**Prop 65 Warning -** Handling the coated electrical wires of this product exposes you to Lead, a chemical known to the State of California to cause cancer, birth defects and other reproductive harm. Wash hands after use.