369427g 1 07.18.13


PowPak® Dimming Module with EcoSystem®

The PowPak® Dimming Module with EcoSystem® is a radio frequency (RF) control that operates up to 32 EcoSystem® Ballast/LED drivers based on input from Pico® controls and Radio Powr Savr™ sensors. Configurable for multiple zones in a single area, the Dimming Module with EcoSystem® is ideal for small areas such as classrooms, conference rooms, and private offices.

Communication with RF input devices, such as Pico® controls and Radio Powr Savr™ sensors, is accomplished using Lutron® Clear Connect® RF Technology.

Features

- Controls up to 32 EcoSystem® fluorescent dimming ballasts and LED drivers
- Various operating voltages available refer to model number chart below for details on voltage requirements
- Receives input from up to nine Pico® controls, six Radio Powr Savr™ occupancy/vacancy sensors, and one Radio Powr Savr™ daylight sensor
- Utilizes Lutron_® Clear Connect_® RF Technology refer to model number chart below for frequency band data
- Mounts to a U.S. style junction box through a standard size knockout
- Complies with requirements for use in a compartment handling environmental air (plenum) per NEC_® 2011 300.22(C)(3) (RMJ- and URMJ- models only)



RMJ-ECO32-DV-B model shown

Model Number	Region	Operating Voltage	Frequency Band
RMJ-ECO32-DV-B	U.S.A., Canada, Mexico	120/277 V∼	431.0 – 437.0 MHz
URMJ-ECO32-DVB	U.S.A. (BAA Compliant)	120/277 V∼	431.0 – 437.0 MHz
RMQ-ECO32-DV-B	Hong Kong	220 – 240 V~	433.05 – 434.79 MHz
RMM-ECO32-DV-B	China and Singapore	220 - 240 V~	868.125 – 868.475 MHz
RMK-ECO32-DV-B	Europe, U.A.E.	220 – 240 V~	868.125 – 868.850 MHz
RMN-ECO32-DV-B	India	220 – 240 V~	865.5 – 866.5 MHz
RMP-ECO32-JA-B	Japan	100 V∼	313.3 – 314.8 MHz
RMP-ECO32-200-JA	Japan	200 V∼	313.3 – 314.8 MHz

NOTE: Contact Lutron for frequency band compatibility for your geographic region if it is not indicated above.

Job Name:	Model Numbers:
Job Number:	

369427g 2 07.18.13

Specifications

Regulatory Approvals RMJ- & URMJ- models only

- UL Listed (U.S.A.)
- UL 2043 Plenum Rated (U.S.A.)
- FCC approved. Complies with the limits for a Class B device, pursuant to Part 15 of the FCC rules. (U.S.A.)
- CSA and IC (Canada) (RMJ Only)
- COFETEL (Mexico) (RMJ Only)
- NOM (Mexico) (RMJ Only)

RMN- Model

• WPC Type Approved (India)

RMK- Model

- CE (European Union)
- TRA Type Approved (United Arab Emirates)

Power

• Operating voltage:

RMJ/URMJ- models $120/277 \text{ V} \sim 50/60 \text{ Hz} \ 40 \text{ mA}$ **RMQ-, RMM-, RMK-, RMN- models** $220-240 \text{ V} \sim 50/60 \text{ Hz} \ 40 \text{ mA}$ **RMP- models** $100 \text{ V} \sim 50/60 \text{ Hz} \ 40 \text{ mA}$

- Typical system power consumption (12 ballasts): 2.0 W
- Full system power consumption (32 ballasts): 2.75 W

System Communication

- Operates using Clear Connect_® RF Technology for reliable wireless communication; refer to model number chart on page 1 for frequency band details
- RF range is 30 ft (9 m) for RMJ-, URMJ-, RMQ-, RMM-, RMK-, RMN- models
- RF range is 23 ft (7 m) for RMP- models
- Contact Lutron first for applications using foil-backed or metallic ceiling tiles.

Default Operation

- Associated wireless input devices control all connected EcoSystem_® LED drivers
- Occupancy Sensors:
 - Occupied: 100%; Unoccupied: 0% (OFF)
- Pico_® Controls:
 - On: 100%; Favorite Level: 50%; Off: 0% (OFF)
- Daylight Sensor: Decreases electric light in response to additional available daylight

Environment

- Ambient operating temperature: 32 to 104 °F (0 to 40 °C)
- 0 to 90% humidity, non-condensing
- For indoor use only

EcoSystem_® Link

- 18 V== 125 mA
- Communicates with up to 32 EcoSystem® dimming ballasts, LED drivers and interfaces such as CJ-BMJ-16A (U.S.A. only)
- EcoSystem_® Digital Link can be wired Class 1 or Class 2 for maximum wiring flexibility (RMJ-, URMJ-, RMM-, RMN-, RMQ- models)
- EcoSystem_® Digital Link carries basic isolation from line voltage wires (RMK- model)
- Terminals accept 18 to 16 AWG (0.75 to 1.5 mm²) solid wire

NOTE: Must use Rapid Start sockets with EcoSystem_® ballasts.

NOTE: The PowPak® Dimming Module with EcoSystem® does NOT support the C5-XPJ-16A switching module.

NOTE: Wired sensors connected to EcoSystem® devices are NOT supported.

Key Design Features

- LED status indicators show communication status and provide programming feedback
- Power failure memory: If power is interrupted, connected loads will return to the previous level prior to interruption
- EcoSystem_® link miswire protection up to 347 V ~
- Daylight override: Pressing the raise button on an associated Pico
 ontrol will temporarily override daylighting for the fixtures in that Pico
 group
- Daylighting will be re-enabled for that Pico_® group when one of the following occurs:
 - Two hours have passed since the override.*
 - ON, OFF or Preset button has been pressed on a Pico_® control controlling that group.
 - All associated Occupancy Sensors have reported unoccupied.

Page

* Each time a daylighting override occurs for any Pico® group, the two hour timer is reset.


©LUTRON ® SPECIFICATIO	N SUBMITTAL
Job Name	Model Numbers:


Job Name:	Model Numbers:
Lab Nharah am	
Job Number:	

369427g 3 07.18.13

Dimensions


Dimensions are shown as: in (mm)






Range Diagrams

RMJ-, URMJ-, RMQ-, RMM-, RMK-, RMN- models



All Wireless Transmitters must be installed within 30 ft (9 m) of the PowPak™ Relay Module.

RMP- models




All Wireless Transmitters must be installed within 23 ft (7 m) of the PowPak™ Relay Module.

LUTRON SPECIFICATION SUBMITTAL

Job Name:	Model Numbers:
Job Number:	


369427g 4 07.18.13

System Diagram (RMJ-, URMJ-, RMQ-, RMM-, RMN- models)



Radio Powr Savr™ Daylight Sensor (up to 1)

Wiring Diagram (RMJ-, URMJ-, RMQ-, RMM-, RMN- models)




* NOTE: Some applications (in USA) require the PowPak® module to be installed inside an additional junction box. For information about how to perform this installation, please visit www.lutron.com, Application Note #423 (P/N 048423). Please consult all local and national electronic codes for proper installation methods.

LUTRON SPECIFICATION SUBMITTAL

		9
Job Name:	Model Numbers:	
Job Number:		


369427g 5 07.18.13

System Diagram (RMP- models)



Radio Powr Savr™ Daylight Sensor (up to 1)

Wiring Diagram (RMP- models)




LUTRON SPECIFICATION SUBMITTAL

Job Name:	Model Numbers:
Job Number:	


369427g 6 07.18.13

System Diagram (RMK- model)



Radio Powr Savr $_{\text{\tiny TM}}$ Daylight Sensor (up to 1)

Wiring Diagram (RMK- model)



★ NOTE: Some applications (in USA) require the PowPak⊕ module to be installed inside an additional junction box. For information about how to perform this installation, please visit www.lutron.com, Application Note #423 (P/N 048423). Please consult all local and national electric codes for proper installation methods.

LUTRON SPECIFICATION SUBMITTAL


Job Name:	Model Numbers:
Job Number:	

369427g 7 07.18.13

Advanced Configurations

Pico_® Wireless Controls


- Up to nine Pico® controls, each with their own control group
- Each group can include any of the connected drivers
- Favorite levels can be set for each Pico® wireless control



Radio Powr Savr™ Daylight Sensor

- Up to two daylighting rows can be configured
- The Radio Powr Savr
 m daylight sensor group can include up to 32 drivers

Minimum Light Level Setting (optional)



 Certain applications, such as hallways, may require that the lights never turn off. For these areas, select the 10% minimum light level option.


High-End Trim

- The maximum light output of connected drivers can be decreased by up to 50% for energy savings in over-lit spaces
- High-End Trim affects all connected drivers equally, and can be configured from the dimming module or from any associated Pico_® control


Radio Powr Savr™ Occupancy Sensors

- Radio Powr Savr™ occupancy and vacancy sensors control all connected drivers
- Grouped Pico® controls can be used to adjust the Occupied levels of drivers that they control from 1 to 100% or can make them unaffected by Occupancy events
- Vacancy events (area becomes unoccupied) turn all drivers off or to 10%, if minimum light level is set

Occupied



Unoccupied



SPECIFICATION SUBMITTAL

W. LO III O I I CONTOUT GOD WITH THE		ı ago
Job Name:	Model Numbers:	
Job Number:		